INSTRUCTIONS FOR USING THE MINI WILSON(TM) DIGITAL VOICE CARD RECORDER

Congratulations on purchasing The Mini Wilson(TM), a state-of-the-art digital voice card recorder. The following are instructions for its use:

Batteries:

The Mini Wilson(TM) comes with a built-in lithium-ion rechargeable battery. Before using the device, you must charge the battery

Charging The Mini Wilson(TM) recorder battery:

Connect the Micro USB plug end of the USB cable (included) into the Mini Wilson(TM) recorder and the other end in to your computer or a Micro USB adapter (Smart Phone's Micro USB Adapter). The red led stays ON continuously to indicate that the charging is in progress. Once the battery is fully charged, the LED will go off. You can charge the battery, whether the unit is off or in use.

Note: The Mini Wilson(TM) will retain all existing messages when battery is low.

Recording:

To record, press the Record button (REC). After the beep, speak in the direction of The Mini Wilson(TM). The recording indicator blue LED light will flash, indicating that The Mini Wilson(TM) is recording. During recording, pressing the PAUSE button will pause the recording. the blue LED light will stay on. Press the PAUSE again to resume the recording. To stop recording, press the Play/Stop button. The Mini Wilson(TM) will beep twice, indicating that the recording has stopped. Alternatively, The Mini Wilson(TM) will automatically cease recording if the memory is full (the LED will turn off). You can record messages for a total recording time of up to 1 hour.

Play Back:

To play back your message, simply press the Play/Stop button. The Mini Wilson(TM) will play back the most recently recorded message first. Each time the Play/Stop button is pressed thereafter, The Mini Wilson(TM) will play all recorded messages newest to oldest in order.

If there are no messages inside The Mini Wilson(TM), it will beep once each time you press the Play/Stop button.

Deleting Messages:

To delete a message, press the Delete button (DEL) twice in quick succession while playing the message you wish to delete. The Mini Wilson(TM) will beep twice to indicate the message is being deleted.

Standby mode:

The Mini Wilson(TM) will enter the standby mode automatically after playback or after recording. The PAUSE button and the DELETE button have no effect during standby mode.

Patent Pending

Page 1 of 2

DISCLAIMER

No liability is assume4, directly or indirectly, any damage or loss resulting from the use of The Mini Wilson(TM). The manufacturer assumes no responsibility for data loss, improper use, damage, repairs, defects, battery use or replacement, or any other costs.

Repair or replacement, as provided under the Limited Warranty, shall be the exclusive remedy of the consumer. Talk to the Wilson, LLC shall not be liable for incidental or consequential damages resulting from the use of The Mini Wilson(TM) or arising out of any breach of any express or implied warranty with respect to The Mini Wilson(TM).

LIMITED WARRANTY

Talk to the Wilson, LLC grants a limited warranty for The Mini Wilson(TM) for 1 year from the date of purchase. Please retain the sales receipt as proof of purchase. During the warranty period, The Mini Wilson(TM) is eligible for repair or replacement in the event of defects in materials or workmanship. In such cases, the defective product will be repaired or replaced as determined by Talk to the Wilson, LLC, in its sole discretion. Notwithstanding the preceding, this limited warranty does not cover damages caused by accident, improper use or unauthorized modifications. In addition, this limited warranty does not cover expendable materials and defects which constitute normal wear and tear. Please contact Talk to the Wilson, LLC, via our website (www.talktothewilson.com) for limited warranty questions or service.

Please note: Retailer is not responsible for warranty claims. Do not return to retailer. Any claims should be sent directly to Talk to the Wilson, LLC.

Talk To The Wilson. LLC. 10105 E. Via Linda #103 - 196 Scottsdale, AZ 85258-5311 1-866-551-1588

Email: sales@talktothe wilson.com

Made in China

Page 2 of 2